CROSSCALL

X-TALK

HOW TO

On a CORE-P6



HOW TO

MAKE A ONE-TO-ONE PTT CALL

HOW TO: MAKE A ONE-TO-ONE PTT CALL

Use the Touch Pad to navigate. Press the center button to select.



Select the **contact list**.



Your **contact list** opens.



Select a **contact**. Press the **PTT button** to start the call.



The **red phone icon** means the connection is ready. **Press and hold the PTT button** to speak.



Wait for the **tone** and **green LED**, then speak. Keep the **PTT button held down** while speaking.



To end the call, select the **red phone icon** at the bottom left using the **Touch Pad**.

HOW TO
RECEIVE A ONE-TO-ONE PTT CALL

HOW TO: RECEIVE A ONE-TO-ONE PTT CALL





When a contact calls, you hear a **tone** and a **red phone icon** appears at the bottom left.



When the contact speaks, their **name** appears on screen.



To end the call, select the **red phone icon** at the bottom left using the **Touch Pad**.

HOW TO
SELECT A GROUP

HOW TO: SELECT A GROUP



Use the **Touch Pad** to open the **group list**.



Your **group list** opens.



Select a **group**. When it turns **green**, press the **PTT button** to confirm.



The **main screen** opens with your selected group. You can now talk to the group.

HOW TO
TALK TO A GROUP

HOW TO: TALK TO A GROUP

FROM THE MAIN SCREEN



From the main screen, **press and hold the PTT button** to speak to the selected **group**.



Wait for the **tone**, **green LED** and **"You"** on screen, then speak. Keep the **PTT button held down** while speaking.

HOW TO
LISTEN TO A GROUP

HOW TO: LISTEN TO A GROUP



When connected to a **group**, you can hear its members speak **one at a time**.



When a member speaks, their **name** appears on screen. The **group name** appears at the top.

HOW TO
SWITCH GROUPS

HOW TO: SWITCH GROUPS



Turn the **rotary knob** to switch groups.



The screen shows the **selected group's name**. The device also **announces the name**.

Group sequence

The rotary knob cycles through your groups. For example, with 3 groups, positions 1, 2 and 3 select Groups 1, 2 and 3. Position 4 returns to Group 1, position 5 selects Group 2, and position 6 selects Group 3. The sequence then repeats.

HOW TO MAKE MULTIGROUP LISTENING

HOW TO: PRIORITIZE GROUPS



Use the **Touch Pad** to open the **group list**.



Your **group list** opens.



Select the **groups** to hear and set their **priority**. Press the **PTT button** to confirm.



The **two selected groups** appear on screen. You can hear members speaking in either group.

HOW TO: PRIORITIZE GROUPS

LISTENING



As User A, you hear User C speaking in Group A.

As User A, you hear User B speaking in Group B.

You switch automatically between Group A and Group B when someone speaks. If User C and User B speak at the same time, you hear User C because Group A has priority 1.

HOW TO: PRIORITIZE GROUPS

SPEAKING



As User A, when you speak in Group A, User C hears you.

As User A, when you speak in Group B, User B hears you.

Press and hold the PTT button to speak to the group highlighted in blue. To switch groups, use the Touch Pad to select the group name.

HOW TO: MAKE A CONFERENCE CALL



Select the **contact list**.



Your **contact list** opens.



Use the **Touch Pad** to select the **contacts**. Press the **PTT button** to start the call.



The **red phone icon** means the connection is ready. **Press and hold the PTT button** to speak.



Wait for the **tone** and **green LED**, then speak. Keep the **PTT button held down** while speaking.



To end the call, select the **red phone icon** at the bottom left using the **Touch Pad**.

HOW TO
MAKE A VIDEO CALL

HOW TO: MAKE A VIDEO CALL

TO A CONTACT



Use the **Touch Pad** to open the **contact list**.



Navigate to the **contact** with the **Touch Pad**. **Press and hold the center button** to open the menu.



Select **Video Call**.



The **video call screen** opens.



Select **Leave meeting** to leave the call, or **End meeting for all** to end it for everyone.

HOW TO: MAKE A VIDEO CALL

TO A GROUP



Use the **Touch Pad** to open the **group list**.



Navigate to the **group** with the **Touch Pad**. **Press and hold the center button** to open the menu.



Select **Video Call**.



The **video call screen** opens.



Select **Leave meeting** to leave the call, or **End meeting for all** to end it for everyone.

HOW TO
MAKE AN EMERGENCY CALL

HOW TO: MAKE AN EMERGENCY CALL



Press and hold the SOS button for **3 seconds**.



The **emergency call starts** and you hear **"Emergency on"**. Select **Dismiss** using the **Touch Pad**, or wait for the window to close. The **emergency remains active**.



"In Emergency" appears at the bottom of the screen. To stop the emergency, **press and hold the SOS button** again for **3 seconds**. You hear **"Emergency off"**.

During an emergency call, you can only talk within the current group. You cannot switch groups or call an individual contact.

HOW TO: RECEIVE AN EMERGENCY CALL

WHEN YOU SEE THE NOTIFICATION



An **emergency notification** appears. Use the **Touch Pad** to select **Locate**.



Google Maps opens in the browser. Select the option to **stay on the website**.



The person's **GPS coordinates** appear.

HOW TO: RECEIVE AN EMERGENCY CALL

IF YOU MISS THE NOTIFICATION



An **emergency notification** appears, but you **miss it**.



A **red message icon** shows that you missed an important notification. Select it using the **Touch Pad**.



The **missed emergency call** appears. Select the **location link**.



Google Maps opens in the browser. Select the option to **stay on the website**.



The person's **GPS coordinates** appear.

HOW TO
USE MAN DOWN ALERTS

HOW TO: USE MAN DOWN ALERTS

WITH A DEDICATED SOS BUTTON



If you **fall with your device**, an alarm sounds. After a **15-second countdown**, the Man Down alert starts. This also works when the **device is locked**.



The **Man Down alert starts** and you hear **"Warning Man Down"**. Select **Dismiss** using the **Touch Pad**, or wait for the window to close. The **alert remains active**.



"In Man Down State" appears at the bottom of the screen. To stop the alert, **press and hold the SOS button** for **3 seconds**. You hear **"Man down off"**.

During a Man Down alert, you can only talk within the current group. You cannot switch groups or call an individual contact.

HOW TO RECEIVE A MAN DOWN ALERT

HOW TO: RECEIVE A MAN DOWN ALERT

WHEN YOU SEE THE NOTIFICATION



A **Man Down notification** appears. Use the **Touch Pad** to select **Locate**.



Google Maps opens in the browser. Select the option to **stay on the website**.



The person's **GPS coordinates** appear.

HOW TO: RECEIVE A MAN DOWN ALERT

IF YOU MISS THE NOTIFICATION



A **Man Down notification** appears, but you **miss it**.



A **red message icon** shows that you missed an important notification. Select it using the **Touch Pad**.



The **missed Man Down alert** appears. Select the **location link**.



Google Maps opens in the browser. Select the option to **stay on the website**.



The person's **GPS coordinates** appear.

HOW TO
CHANGE YOUR STATUS

HOW TO: CHANGE YOUR STATUS



Press the **menu/shortcut key** at the top left of the keypad.



Select **Off duty**.



Select **OK** using the **Touch Pad**. The app's screen stays the same.

When you are off duty, Man Down detection is off. A fall will not trigger a Man Down alert.

HOW TO
SEND A MESSAGE TO A CONTACT

HOW TO: SEND A MESSAGE TO A CONTACT



Use the **Touch Pad** to select the **message icon**. A **red icon** means you missed an emergency or Man Down notification.



Your **main group's chat** opens. Press the **Back button** to choose another chat.



Select the **contact** using the **Touch Pad**.



Type your message using the **keypad**. Select the **send arrow**.



Select the **paperclip icon** to send photos, audio, a document or your location. You can also take a photo or record a video.

HOW TO
SEND A MESSAGE TO A GROUP

HOW TO: SEND A MESSAGE TO A GROUP



Use the **Touch Pad** to select the **message icon**. A **red icon** means you missed an emergency or Man Down notification.



Your **main group's chat** opens. Type your message using the **keypad**, then select the **send arrow**.



Select the **paperclip icon** to send photos, audio, a document or your location. You can also take a photo or record a video.

To message another group, press the Back button. Use the Touch Pad to select a group.

You can also change your main group. Its chat will then open by default when you select the message icon.