

CROSSCALL CORE-P6 - HOW TO INSTALL FIRSTNET FUSION

Please follow these steps to use the Fusion app on your CORE-P6 device.

- 1** Navigate to **Settings** from the CORE-P6 home screen



- 2** If your CORE-P6 is being used for the first time, please skip to Step 6. Select **Device**, tap **Apps**, and select your last active Push-to-Talk (PTT) application



- 3** Tap **Force Stop**, then go to **Storage & Cache**



- 4** Select **Clear Storage** and **Clear Cache** to completely erase data.



- 5** Press the back button five times to return to the main **Settings** menu.



- 6** Select **Customization**, tap **Buttons**, and pick either the **PTT** or **Emergency** hardware key.



- 7** Select **Fusion** to reassign the button.



- 8** Launch your FirstNet Fusion PTT application from the home screen.

